

Drift Cutter Assembly

For deep snow, install drift cutters for maximum reach.



#1 – Align holes on drift cutter with holes on auger shroud.



#2 – Use black knob and bolt to attach lower hole on drift cutter to auger housing first.

Drift Cutter Assembly



#3 – Use black knob and bolt to attach upper hole on drift cutter to auger housing.

#4 – Repeat steps #2, #3 for other side.



Final assembly appearance



Storage position